

---

# PSA User Manual

## *TaskLink Special Feature setting:*

---

**Product State Awareness:** Default <Disable>. Setting to <Enable> will enable PSA function.

**Product State Awareness Mode:** Default <selected by system>, the algorithm will check which mode this device support, if support both, auto mode is selected.

Customer can specify Manual mode or Auto mode by this special feature.

**PSA state after programming for manual mode:**

Default <PRE\_SOLDERING\_POST\_WRITES>. Standard eMMC protocol will set PSA state to pre\_soldering\_post\_writes (ECSD[133]), but Micron request the option to set PSA state to NORMAL after off-line programming for some devices.