

SKIP MPF BCH8 BBT User Manual

It uses skip method for bad blocks handling within each partition, bad blocks within any partition do not affect the starting location of the follow up partitions. The first 3 blocks are used to store the partition table, the last 2 blocks are used to store BBT. The binary image does not contain spare area.

Relevant User Options

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address: <http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = “SKIP MPF BCH8 BBT”

Spare Area = “Disabled”

- This option should be selected for this BBM.

Error bits allowed in one page = “?”

- How many error bits allowed during preprogramming. Default value is 0, do not allow any error bits.

This Document's versions-

V1.0: 01/25/2021 - Original version

Appendix

You can get the file “Description of common NAND special features.pdf” from <http://ftp.dataio.com/FCNotes/BBM>